

# INSTALLATION EXAMPLE

ELECTRICAL CONNECTION SIDE

ADJUST to 15mm  
N° 6 RUBBER FEET  
IF MACHINE IS INSTALLED  
ON BASE cod.6550

N°2 COVERS  
NOT INCLUDED

B DETAIL  
SCALE 1 : 2

REMOVE COVER  
FOR POWER  
CONNECTION

SEAL AFTER  
INSTALLATION

[35,433]  
900

Minimum reccomended  
size base cabinet

BASE CABINET  
NOT INCLUDED

IMPORTANT  
DO NOT OBSTRUCT  
THE GAP

[18,898]  
Ø 480  
NITROGEN GAS PIPE  
DIAMETER RANGE Ø 400-480

[5,315]  
Ø 135  
NECESSARY  
DIAMETER  
FOR ELECTRICAL  
POWER CONNECTION  
AND LAN CONNECTION

[1,417]  
36

[0,591]  
15

[0,118]  
3

COUNTERBORE  
FOR RUBBER FEET  
RESPECT PROVIDED  
DIMENSION

[35,433] BASE CABINET  
Ø 900 NOT INCLUDED

EXAMPLE TYPICAL  
BASE CABINET  
DIMENSION

**enomatic®**  
wine serving systems

TITLE:  
**ENOROUND 16 BOTTLE ELITE  
8+8**

DWG NO. **ER4-YMOTA** A3  
SCALE:1:10 LANGUAGE: ENGLISH FINISH: THICKNESS: SHEET 1 OF 1

PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS  
DRAWING IS THE SOLE PROPERTY OF  
<INSERT COMPANY NAME HERE>. ANY  
REPRODUCTION IN PART OR AS A WHOLE  
WITHOUT THE WRITTEN PERMISSION OF  
<INSERT COMPANY NAME HERE> IS  
PROHIBITED.

REV.	DESCRIPTION	DATE	EXECUTOR	CHK'D	APPV'D
CODE:	MATERIAL:			MATERIAL CODE:	WEIGHT Kg:
-----	---				---